







wired

Operating and Installation Instructions public II with headset wired

Operating and Installation Instructions public II with headset

Connecting a heads	et
--------------------	----

Type

- Insert the plug of the headset into the jack at the lower case part of the microphone loudspeaker unit public II.
- Press the ON/OFF key for approx. 3 sec for RESET in case of initial operation or power failure (relay click!).
- 3. Two operating modes are possible:
 - a) via microphone of the microphone loudspeaker unit
 - b) via microphone of the headset
- 4. Changing the operating mode:

Press the *ON/OFF key* for approx. 3 sec (refer point 2). Then press again the **ON/OFF** key:

- --> green led flashes
- = the headset is activated
- —> green led *lights permanently* = the microphone of the microphone loudspeaker unit is activated
- If required, volume can be adjusted for both operating modes via potentiometer located at the lower part of the microphone loudspeaker unit public II.
- For all other functions, please refer to the *public II* operating instructions.

Connecting a headset

Type

- Insert the plug of the headset into the jack at the lower case part of the microphone loudspeaker unit public II.
- Press the ON/OFF key for approx. 3 sec for RESET in case of initial operation or power failure (relay click!).
- 3. Two operating modes are possible:
 - a) via microphone of the microphone loudspeaker unit
 - b) via microphone of the headset
- 4. Changing the operating mode:

Press the *ON/OFF key* for approx. 3 sec (refer point 2). Then press again the **ON/OFF** *key*:

- --> green led *flashes* = the headset is activated
- —> green led *lights permanently* = the microphone of the microphone loudspeaker unit is activated
- If required, volume can be adjusted for both operating modes via potentiometer located at the lower part of the microphone loudspeaker unit public II.
- For all other functions, please refer to the *public II* operating instructions.